

NOTES:

- TRACER WIRE SYSTEM SHALL BE COPPERHEAD TRACER WIRE SYSTEM (OR APPROVED EQUAL)
- TRACER WIRE SYSTEM SHALL BE INSTALLED PER MANUFACTURER AND NTM SPECIFICATIONS.
- 3. WIRE SHOWN AWAY FROM PIPE FOR CLARITY. WIRE SHALL BE INSTALLED ON THE BOTTOM SIDE OF THE PIPE BELOW THE SPRING LINE.
- 4. THE WIRE SHALL BE FASTENED TO THE PIPE WITH TAPE OR PLASTIC TIES AT 5' INTERVALS

